

Tools Needed:

19/64 drill bit

PVC primer (for 3/4" barbed fittings only)

PVC cement (for 1/4" barbed nipple only)

Steps:

- 1.) Drill a hole in the PVC elbow using the 19/64 drill bit
- 2.) Use PVC Cement to attach the 1/4" bleedline nipple to the elbow.
DON'T USE PRIMER. If you use primer, the bleedline nipple will go limp.



- 3.) Attach the 3/4" barbed fittings to both sides of the elbow using PVC primer + PVC Cement



- 4.) Wait 24 hours for PVC Cement to dry on 1/4" bleedline nipple
TIP: Heat up the 1/4" vinyl tubing with a hair dryer or a cup of hot water so the tubing can be GENTLY attached to the bleedline fitting
- 5.) After 24 hours, GENTLY attach the 1/4" vinyl tubing to the bleedline fitting