Installing the Floating Weir and Removal of the Safety Suction Assembly

NOTE: For Older Tiger River Models Only

Recommended Tools

Required Supplies

Spring Clamp Pliers Hose Clamping Pliers Floating Weir Kit (PN 71944)

- 1. Remove the filter lid.
- 2. Unscrew the filter cap and remove the filter from the well.
- 3. Remove the current weir by pulling it straight out.
- 4. Install the <u>floating weir</u> by inserting it at a slight angle into the filter opening and pushing it in until it snaps into place.
- 5. Replace the filter and cap.
- 6. Replace the filter lid.
- 7. Remove the equipment compartment door.
- 8. Located the check valve on the left side of the equipment compartment. (See Figure 1).




Figure 1

- 9. Pinch off the ¹/₄" line below the check valve using the hose clamping pliers.
- 10. Using the spring clamp pliers slide the spring clamp off the check valve.
- 11. Remove the safety suction assembly.
- 12. Install the ¼" plug onto the ¼" line. Reinstall the spring clamp.
- 13. Remove the hose-clamping pliers.
- 14. Inspect for leaks.
- 15. Verify all spa functions.
- 16. Replace the equipment compartment door.