

NEW

NEW LIMELIGHT INSTRUCTION

IMPORTANT
NEW INSTRUCTIONS

KEEP WITH INSTRUCTIONS

For optimal chlorine generation and cell life:

At the time of initial spa fill-up, add 100% of the required salt in one dose. Specific per model dosing instructions are included in the Owner's Manual.

Ensure that the spa has enough added salt such that the ACE[®] salt meter indicator is 40 - 75% of the green OK range. Add any additional salt up to 1750 ppm to achieve this level.

LIMELIGHT INSTRUCTIONS

The ACE cell is configured for operation in HotSpring Highlife spas. When used in Limelight spas, the cell's cable length needs to be extended to one of two additional lengths. The cable is premarked showing the two new strain relief locations.

Locate the appropriate mark:

- a. For all Pre-2018 models except Gleam, use the first mark. (14.375" from bottom of cell)
 - b. For the Gleam, use the second longer mark (20.375" from bottom of cell)
 - c. For 2018-current models, use the second mark (16.5 inch from the bottom of cell).
2. Loosen the strain relief on the filter cap.
 3. Align the top of the strain relief at the appropriate mark so that the mark is barely visible.
 4. Tighten the strain relief.

PN 62812 Rev. D (08/18)

IMPORTANT
NEW INSTRUCTIONS

NEW

NEW LIMELIGHT INSTRUCTION

IMPORTANT
NEW INSTRUCTIONS

KEEP WITH INSTRUCTIONS

For optimal chlorine generation and cell life:

At the time of initial spa fill-up, add 100% of the required salt in one dose. Specific per model dosing instructions are included in the Owner's Manual.

Ensure that the spa has enough added salt such that the ACE[®] salt meter indicator is 40 - 75% of the green OK range. Add any additional salt up to 1750 ppm to achieve this level.

LIMELIGHT INSTRUCTIONS

The ACE cell is configured for operation in HotSpring Highlife spas. When used in Limelight spas, the cell's cable length needs to be extended to one of two additional lengths. The cable is premarked showing the two new strain relief locations.

Locate the appropriate mark:

- a. For all models except Gleam, use the first mark. (14.375" from bottom of cell)
 - b. For the Gleam, use the second longer mark (20.375" from bottom of cell)
 - c. For 2018-current models, use the second mark (16.5 inch from the bottom of cell).
2. Loosen the strain relief on the filter cap.
 3. Align the top of the strain relief at the appropriate mark so that the mark is barely visible.
 4. Tighten the strain relief.

PN 62812 Rev. D (08/18)

IMPORTANT
NEW INSTRUCTIONS